



VIDEO TUTORIAL

### Important!

This replacement procedure can be used for:

VW BEETLE (5C1, 5C2) 2.0 TSI, VW BEETLE Convertible (5C7, 5C8) 2.0 TSI, VW CC (358) 2.0 TSI, VW EOS (1F7, 1F8) 2.0 TFSI, VW GOLF V (1K1) 2.0 GTI, VW GOLF V Variant (1K5) 2.0, VW GOLF VI (5K1) 2.0 GTi, VW JETTA III (1K2) 2.0 TFSI, VW JETTA IV (162, 163, AV3, AV2) 2.0 TSI, VW PASSAT (3C2) 2.0 FSI, VW PASSAT CC (357) 2.0 TSI, VW PASSAT Variant (3C5) 2.0 FSI, VW TIGUAN (5N\_) 2.0 TFSI 4motion

---

The steps may slightly vary depending on the car design.

## REPLACEMENT: ANTI ROLL BAR LINKS – VW GOLF 6. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #18
- XZN socket bit # 6
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Wheel chock

### AUTODOC recommends:

- Replace the stabiliser links on VW Golf 6 in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

## REPLACEMENT: ANTI ROLL BAR LINKS – VW GOLF 6. RECOMMENDED SEQUENCE OF STEPS:

1



Secure the wheels with chocks.

2



Loosen the wheel mounting bolts. Use wheel impact socket #17.

3



Raise the front of the car and secure on supports.

4




Unscrew the wheel bolts.

### AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. VW Golf 6

5



Remove the wheel.



6



Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.

7



Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #18. Use XZN #6. Use a ratchet wrench.

8



Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.

9




Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #18. Use XZN #6. Use a ratchet wrench.

10



Remove the stabilizer rod.

11



Install a new rod, tighten the fasteners.



12



Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #18. Use XZN #6. Use a torque wrench. Tighten it to 55 nm torque.

13



Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #18. Use XZN #6. Use a torque wrench. Tighten it to 55 nm torque.

14



Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.

15



Install the wheel.

### AUTODOC recommends:


- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW Golf 6

16



Screw in the wheel bolts. Use wheel impact socket #17.

17



Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 Nm torque.

18



Remove the jacks and chocks.



**DID YOU FIND THESE INSTRUCTIONS  
HELPFUL?**

**YES**

**NO**



**BECOME A MEMBER OF AUTODOC CLUB!**

## AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



The advertisement features two smartphones. The foreground phone displays the AUTODOC app interface with a '23% RABATT PÅ RESERVEDELER' (23% discount on spare parts) banner, a category list including 'Vindusvask', 'Oljer og Væsker', 'Bremseanlegg', and 'Filter', and a 'Filter' button. The background phone shows a grid of various car parts. To the right, the 'AUTODOC APP' logo is displayed above three buttons: an orange 'Download' button, a 'Google play' button with the Google Play logo, and an 'App Store' button with the Apple logo.

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



## BUY SPARE PARTS FOR VW



## ANTI ROLL BAR LINKS: A WIDE SELECTION



### CHOOSE CAR PARTS FOR VW GOLF 6



### ANTI ROLL BAR LINKS FOR VW: BUY NOW





## ANTI ROLL BAR LINKS FOR VW GOLF 6: THE BEST DEALS & OFFERS



### Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.